

How to replace your chalkboard panel



You will need:

- A new, black chalkboard panel
- A Phillips head screwdriver

Instructions:

1. Unscrew the 6 screws (3 each side) holding chalkboard into place, and set aside 4 of the screws.
2. Dispose of the green chalkboard surface. DO NOT reuse, donate, or give away.
3. Unpack your black chalkboard panel and use the 4 screws you set aside to attach the new, black panel.

Note: It is possible that your screw holes will not line up the first time you position the panel. If this is the case, rotate the chalkboard panel 180° and try again. If the holes still do not line up you will need to screw the bottom screws directly into the wood. This can be done with the Phillips head screwdriver or, preferably, with a drill fitted with a Phillips head bit.



Questions:

email recall@macphersonart.com
or call toll-free (866) 319-5335
www.art-alternatives.com



*We are sorry for this inconvenience.
Thank you for letting us replace your chalkboard!*